


Congratulations on your purchase of a Rocketfish Wired Headset for your PS3. Your wired headset is designed to connect to a PlayStation® 3 (PS3™) game console.

Package contents



Headset



Quick Setup Guide



Chat Indicator

Lights in Chat mode during online gaming.
Blinks when players are speaking in Chat mode.




In-line volume control

Product features

- Over-the ear design that lets you hear your game while communicating with others
- Built-in microphone
- In-line volume and mute controls
- 15-foot cord for extra mobility

Using your wired headset

- 1 Plug your wired headset's USB cord into a **USB** port on the PS3.



- 2 In the PS3 *Settings* menu:
 - Select **Accessory Settings**.
 - Select **Audio Device Settings**.
 - Set the **Microphone Level** (from 1 to 5).
 - Set the **Input Device** to **USB Headphone Set**.
 - Set the **Output Device** to **USB Headphone Set**.
 - Select **OK**.

Note:

- Use the volume controls on the headset cable to adjust the volume.
- Press and hold the **MUTE** button to temporarily mute the sound. When you release the button, the sound resumes.
- Make sure that the Bluetooth settings are turned off on your game console before you use your headset. See your the documentation that came with your PS3 for instructions.

90-day limited warranty

Visit www.rocketfishproducts.com for details.

Contact Rocketfish:

For customer service please call 1-800-620-2790

www.rocketfishproducts.com

Distributed by Best Buy Purchasing, LLC

7601 Penn Avenue South, Richfield, MN 55423-3645 USA

© 2011 BBY Solutions, Inc., All Rights Reserved

ROCKETFISH is a trademark of Best Buy Enterprise Services, Inc. Registered in some countries. All other products and brand names are trademarks of their respective owners.

Playstation is a registered trademark and PS3 is a trademark of Sony Computer Entertainment, Inc.